


## What's in the Box



## Cleaning & Care



**HAND WASH ONLY.**  
Hand wash your Ninja knives to maintain optimal performance.



**DO NOT** place knives in dishwasher. Dishwashers can reduce performance and longevity of your knives and damage the handles and blades.



Shears separate into two pieces for cleaning. Fully open Scissors with blades pointing away from you, then pull the piece with the hole off the bolt.



Dry knives thoroughly before storing to prevent watermarks and spotting. **DO NOT** touch sharp edge of knife.



Wipe knife block to clean with a damp, not wet, dish towel or paper towel.



For best results, clean stone sharpening wheel every 6 months with running water and a soft bristle brush. **Replace every 2 years.**

Please make sure to read the enclosed Use and Care Guide prior to using.

**NINJA**  
**StaySharp**  
Knife System

## Quick Start Guide

### Sharpening Guide

**IMPORTANT:** Knives arrive sharp. **DO NOT** sharpen immediately. **DO NOT** attempt to sharpen wet or unclean knives. To maintain optimal sharpness, follow the sharpening steps **at least every 2 weeks.**

#### TO SHARPEN:

- Slide lever to bottom of knife block.
- Insert clean Ninja knife into designated sharpening slot until the blade comes to a hard stop.



#### LARGE HANDLE

Insert into upper sharpening slot (Chef and Slicing Knives)




#### SMALL HANDLE

Insert into lower sharpening slot (Utility and Paring Knives)

- While lightly holding the inserted knife, **slide the lever all the way up and down 10 times.** A slight click will be heard when the lever travels all the way to the top and bottom of the block.

**NOTE:** The lever must travel the full length of the block to sharpen, regardless of knife size, as shown here. The upstroke positions the stone sharpening wheel and the downstroke sharpens the knife.



- Ensure the lever is at the bottom of the block. **Push down and hold the release button** while carefully removing the knife
- Rinse and dry knife thoroughly after sharpening to remove metal shavings. If knife has not been returned to preferred sharpness, repeat steps above.

# Sharpener Tips & Tricks

**Frequent sharpening will not damage knives.**



**ONLY** sharpen clean, Ninja branded cutlery.\*




**DO NOT** sharpen Scissors or serrated Bread Knife.




Before inserting knife for sharpening, slide sharpener lever to the bottom of the knife block. This will help prevent damaging the knife.



To remove sharpened knife, push down and hold the release button while carefully removing the knife.



Rinse and dry knife thoroughly after sharpening to remove metal shavings.



If moving the block, remove all knives first. To release suction, gently lift up on the front of the sharpener. Push down to reactivate suction.



Repeat sharpening steps for each clean knife **every 2 weeks.**



If you have any questions while using your cutlery, turn to the Use and Care Guide for more details.

For questions or to register your product, visit us online at [ninjakitchen.co.uk](http://ninjakitchen.co.uk)







 @ninjakitchen.co.uk

\*StaySharp In-Block Sharpener designed for Ninja Knives only. Using other branded knives could damage both your sharpener and knives.

# Recommended Knife Usage



**20cm Chef**  
Multipurpose, versatile knife used for slicing, chopping, mincing, and dicing.




**20cm Slicing**  
Used for cutting thinner slices of larger vegetables, fruit, meat roasts, and cold cuts.



**20cm Bread**  
Used for slicing through bread, tomatoes, and citrus fruit.



**13cm Utility**  
Used for thinner slicing, trimming, and filleting.



**9cm Paring**  
Used for cutting, trimming fat, and peeling small vegetables and fruit.



**Scissors**  
Used for snipping, cutting, and opening packages.



**Looking for recipe inspiration, tips, and tricks?**

visit us at [ninjakitchen.co.uk/cookingcircle.com](http://ninjakitchen.co.uk/cookingcircle.com)

For helpful videos and more



[qr.ninjakitchen.com/staysharp](http://qr.ninjakitchen.com/staysharp)